

**INSTRUCTION SHEET**  
**TO ATTACH 'HGO' AND 'HGE' STYLE GLASS REFLECTORS**  
**TO SUPERBAY (BL) AND TRIBAY (CH) LUMINAIRE HOUSINGS**

Use the four (4) long #10-24 screws provided with glass reflector assembly to attach the glass reflector to the luminaire housing.

**For attachment to Superbay (BL) luminaire housings:**

Thread all four (4) screws provided into the four (4) holes in the housing bottom adjacent to the socket-mounting bracket. This will thread the holes for easier mounting later. If holes not present, wrong housing was provided.

If formed metal cover is required to close off the upper openings on the reflector assembly (HGE for BL), remove all four (4) screws that were threaded in place and loosely attach the cover to the bottom of the housing by placing three (3) of the screws through the inside set of holes (smaller bolt circle) of the cover and into the housing threaded holes. Attach cover leaving the upper left side hole in casting open and make sure the three (3) screws are backed off a few turns. Do not need gasket supplied because it is for wet location operation.

If formed metal cover is not required (HGO for BL), remove the upper left side installed screw and loosen the three (3) other screws a few turns.

Set aside the removed screw for later attachment use.

**For attachment to Tribay (CH) luminaire housing:**

Remove and discard the four (4) screws installed in the bottom of the luminaire housing beside the lamp socket.

Thread all four (4) screws provided into the other outside square pattern holes in the housing bottom. This will thread the holes for easier mounting later.

If formed metal cover and gasket is required (HGE for CH), remove all four (4) screws that were threaded in place. Peel off protective adhesive covering on gasket and attach it onto the outside top of the formed metal cover. Note that the gasket is required for wet location areas. Align the gasket holes with the outside bolt circle holes in the cover. Place three (3) screws through the cover gasket combination holes and into the threaded housing threaded holes. Make sure the three (3) screws are backed off a few turns to loosely attach cover gasket combination to housing.

If formed metal cover is not required (HGO for CH), remove one (1) of the installed screws and loosen the three (3) other screws a few turns.

Set aside the removed screw for later attachment use.

**Attach glass reflector:**

Raise glass reflector assembly up to the bottom of the luminaire housing.

Align keyhole slots in reflector assembly casting over the three (3) screwheads of the loosely, but securely, threaded screws in the housing. These screws are easily accessible on the bottom of the housing or are located on the inside the already attached formed metal cover. Attachment to the Superbay (BL) is through the inside rectangular pattern keyholes and hole and attachment to the Tribay (CH) is through the outside square pattern keyholes and hole.

Orient the hole in the reflector assembly casting over the open hole (missing screw) in the luminaire housing and engage keyhole slots over the screwheads. Rotate reflector to fully engage screwheads in the keyhole slots.

Snug the three (3) screws and install remaining set aside screw into open hole in reflector casting.

Tighten all four (4) attachment screws in a crisscross pattern to secure glass reflector, with or without cover and gasket, to the bottom of the luminaire housing.



Hubbell Lighting, Inc.  
A Subsidiary of Hubbell Incorporated  
2000 Electric Way  
Christiansburg, VA 24073-2500  
(540) 382-6111  
FAX (540) 382-1526

**268-1308-9901**