

INSTRUCTION SHEET TO ATTACH 'HGO' STYLE GLASS REFLECTORS TO EXISTING 'HG' STYLE INDOOR LUMINAIRE HOUSINGS

Adapter kit contains 4 longer mounting screws and a 4" piece of adhesive back dacron felt gasket with peel off covering.

Cut the gasket into equal 2" lengths and apply each strip alongside the lamp socket as shown.

Remove all 4 of the screws holding the bracket onto the luminaire housing and loosely replace them with 3 of the longer supplied screws as shown. This applies for retrofit of the 'HGO' to the Tribay (CH) luminaire.

For the Superbay (BL) luminaire, remove 3 of the 4 screws holding the bracket in place keeping the 1 remaining in place in the upper left or lower right position. This will hold the bracket in place on the luminaire, then loosely replace the removed screws with the longer supplied screws. Next remove the last holding screw.

Install the 'HGO' style glass reflector up onto the luminaire by inserting the keyholes in the top casting over the loosely (but securely) threaded longer screws.

Rotate casting clockwise to fully engage the screws into the keyholes and tighten the screws in a diagonal manner to equally align the top of the reflector casting across the strengthening bars of the mounted 'HG' glass reflector mounting bracket.

Install the 4th remaining longer screw into the open and aligned hole in the top of the casting as shown and tighten screw.

The outside evenly spaced 3 keyholes and 1 separate hole are for attachment to the Tribay (CH) luminaire. The inside 3 keyholes and 1 separate hole are for attachment to the Superbay (BL) luminaire.

Tighten all 4 screws to secure 'HGO' style glass reflector on the luminaire.

